


Bang & Olufsen BtB – Using the Headphone output for Bathroom sound




BeoVision 8-40 BeoVision 10-32, 40, 40 MKII, 46, 46 MKII



The TV software build number has to be 168 or higher.

BANG & OLUFSEN 


Setting up the Headphone output



BANG & OLUFSEN 

Setting up the Headphone output

- If the BtB mode in the TV is enabled, please disable it before proceeding (See the section for Enabling / Disabling the BtB mode)
- Enter the TV setup menu by pressing “MENU” on the remote control.




- Move the cursor to the OPTIONS menu
- Now press “RED” and then “GO” to access the Customer service menu.



BANG & OLUFSEN 

Setting up the Headphone output


- In the CUSTOMER SERVICE MENU, move the cursor to ADJUSTMENTS and press "GO" on the remote.



BANG & OLUFSEN 

Setting up the Headphone output

- In the ADJUSTMENTS menu move the cursor to HP OUTPUT and use the left or right arrow key to change the setting.



Note: Not all menu items are shown in this picture

- The setting can be set to : NORMAL, FIXED LEVEL or FOLLOW TV.




BANG & OLUFSEN 

Setting up the Headphone output

- NORMAL = Uses the normal volume control with separate volume settings for the TV speaker and the Headphone output.
- FIXED LEVEL = Uses the TV startup volume level as a fixed line level on the Headphone output.
- FOLLOW TV = Follows the normal TV speaker volume setting on the Headphone output.
NOTE: In most situations this will be the most suitable setting in a Hotel setup.



Enabling / Disabling the BtB mode



The Westin Excelsior, Rome, Italy




Hilton Copenhagen Airport,
Copenhagen, Denmark



Enabling / Disabling the BtB mode

- Press "Menu, 0, 0, GO" on the remote
- Turn the TV on and press Menu




- Move the cursor to the OPTIONS menu and press "0, 0, GO". Now choose the Business To Business menu.




BANG & OLUFSEN 

Enabling / Disabling the BtB mode

- In the Business To Business menu, the first menu item allows you to enable (ON) or disable (OFF) the BtB mode.
- You can also find the BtB application software version (in this case 6.62v).



The End



B&
B&O
BANG & OLUFSEN